

i@nchor

ANCHOR CONTROL FROM THE HELM

Control anchor depth safely and easily with compact i@nchor control system, ideal for small to mid sized vessels.

Featuring







AMI-TMQ International T: +61 08 9331 0000 | F: +61 08 9314 2929 E: sales@ami-tmq.com | www.ami-tmq.com



Exact anchoring control for real time conditions

Eliminate any quesswork and know exactly how much chain is deployed







i@nchor	TMQ
SETTING Set Limit Sound NZK Data Chain Per Revo Voltage Display Calibrate Sensor Set limits for chain le UP DOWN HOME	P2 Enter ON Data Enter ON Enter
	AUTO

Easy to navigate menu

FEATURES

- Pre-set the length of chain to deploy and set with Automatic deployment feature
- Compatible with most windlasses on the market
- Day or night readability, bright colour display
- Safety features prohibit accidental winch operation
- One touch emergency stop for enhanced safety
- Compact display head is ideal for helms with limited space
- Warns and stops while retrieving at a safe docking distance, which can be set by the user
- Measurement in Metre, feet or Fathoms

