Setting up or reconfiguring GBRMPA Zones from within C-Plot Version 8

1. Start C-Plot Version 8.
2. Double Right click the mouse, this displays the 'Main Menu' window below.



3. Click Settings, this displays the 'Settings' window below,



4. Click Display, this displays the ‘Display Settings’ window below,



5. Click Chart Display, this displays the ‘Chart Display Settings’ window below,



6. Click Change Dataset, this displays the ‘TMQ Closure Zone Dataset Manager’ window below,



7. Click on the GBRMPA Dataset that you require to be displayed. You can click on the name of the Dataset in the Dataset column. Toggles from Active to Not Active each time it is clicked. Check the Status column to see if the required Dataset is either ‘Active’ or ‘Not Active’

8. After you have activated all the Datasets that are required click the ‘OK’ button. The active GBRMPA Datasets will now be displayed in C-Plot.

9. For further Information see the C-Plot Users Manual